



LCD Header J21

Non Gates LCD driver U22

Button Drvr U16

+12Vdc Large HC1 Center Tap J17

J2 GND J3 GND J4 GND

Temp U17 Simulator U16

BDM U15

RESET VOLUME U121 U120 U119

U99 U123 U114

Microphon U1 SPEAKER 8 ohms J28 SPKR w. Amp J27

J10 Display Intensity U100

MOSI U25

BUZZER LS2

U38 U39

U101

SAFETY OUT 1 OUT 2 OUT 3 J17 J16 J20 J19 J18